



UTILITY
SERVICE
TRANSFORMER



UTILITY
METER



UTILITY
MAIN
DISCONNECT



CUSTOMER
TRANSFER
SWITCH



CUSTOMER
SERVICE
PANEL



CUSTOMER
STANDBY
GENERATOR